

# C-BrEase

## Table of contents

---

Beginning .....	4
Welcome .....	4
Why C-BrEase? .....	5
What's New? .....	6
Release History .....	7
Getting Started .....	8
System requirements .....	8
Evaluating C-BrEase .....	9
Getting help .....	9
Program Organization .....	10
General Form .....	10
Chart Form .....	11
File Organization .....	12
General Form .....	12
Menu Items .....	13
License Registration .....	15
License Deactivation .....	16
Project Information .....	17
Vertical Alignment .....	18
Level Grade .....	19
Constant Grade .....	19
Vertical Curves .....	20
Cross Slope .....	21
Constant Cross Slope .....	22
Varying Cross Slope .....	23
Superstructure .....	23
Constant Structural Depth .....	24
Varying Structural Depth .....	24
Substructure .....	27
Cross-Sections .....	29
Date .....	29
Type of Cross-Sections .....	30
Support Data .....	30
Recording Data Points .....	31
Exporting Cross-Sections .....	32
Importing Cross-Sections .....	34
Hydraulics .....	36
Normal Depth Calculator .....	37
Rating Curve .....	41
Risk Estimate .....	41
Scour .....	44
Pier Scour .....	45
Risk Analysis for Scour .....	46
Chart Form .....	47
Creating, Saving and Printing .....	48
View Options .....	50
Panning and Zooming .....	51

Comparing Values .....	51
Cycling through Cross-Sections .....	52
Modifying the Chart .....	53
Modifying the Bridge .....	53
Toggling the Cross-Sections .....	55
Customizing the Lines .....	56
Annotating the Chart .....	58
Text .....	59
Lines .....	61
Rocks .....	61
Polygons .....	62
Pen .....	63
Modifying An Annotation .....	64
Graphically .....	64
Tabularly .....	67
Removing Annotations .....	68
Writing Reports .....	69

## Beginning

---



**Version 1.3.0**

# User Guide

**February 2023**



---

Created with the Standard Edition of HelpNDoc: [Full-featured EPub generator](#)

---

## Welcome

Welcome to **C-BrEase**

**C-BrEase** is a software application written by *H<sub>2</sub>Flo Consulting* for the purpose of making the plotting and analysis of channel cross-sections simple and informative for engineers. First created in 1997, the original program was known as *BrEase* and operated as an application of Microsoft Excel. Rewritten in 2017 using the programming language C# as a stand-alone program, **C-BrEase** now has greater flexibility, improved stability and more capabilities than ever before.

For more information about **C-BrEase** or the services of *H<sub>2</sub>Flo Consulting*, please visit the [website](#).

---

Created with the Standard Edition of HelpNDoc: [Benefits of a Help Authoring Tool](#)

---

## Why C-BrEase?

### Why C-BrEase?

**C-BrEase** provides a streamlined approach to plotting channel cross-sections.

Past studies of bridge failures have demonstrated the essential value of maintaining accurate, graphical records of channel cross-sections at bridge openings to assess channel instability and to identify potential vulnerabilities with the bridge foundation.

**C-BrEase** has been specifically designed to make the calculation of channel cross-sections efficient for the engineer in order to highlight important changes in the channel which might indicate channel stability concerns.

To do this, the program was designed to accurately calculate the channel cross-section data and create plots that relates the historic channel cross-sections with the bridge foundation.

#### Accurate Cross-Section Calculations

To calculate the correct elevation of each cross-section data point, **C-BrEase** accounts for

- Variations in the Bridge Geometrics
  - cross-slope
  - superstructure depths
  - bridge vertical alignment
  - bridge skew
- Adjusts for Measurement Offsets
  - Rail height
  - Tape leader
- Allows for Flexible Data collection methods
  - Laser readings
  - Weighted tape
  - Stationing based on face of substructure item

#### Visually Compelling Plots

To generate meaningful plots of the bridge and channel cross-sections, **C-BrEase** offers

- Flexible Displays
  - Turn on and off different cross-sections
  - Annotate the chart to show key points of interest
  - Quickly adjust the line style, thickness and color of each cross-section
- Interactive Charts
  - Easily zoom into important locations
  - Quickly compare elevation data from various years

---

Created with the Standard Edition of HelpNDoc: [Free Kindle producer](#)

---

## What's New?

## What's New?

**C-BrEase** will be comprised of 3 modules:

1. Historic Channel Cross-Section Monitoring
2. Field Data Collection on Mobile Devices
3. Hydraulic Calculations and Scour Computations

The initial release of **C-BrEase** will only include the cross-section monitoring module.

Compared to earlier versions of *BrEase*, many new features have been added to make **C-BrEase** more useful like

- Greater flexibility to add unique superstructure details and vertical alignments
- Graphical view of individual bridge items during input
- Texture fill for Bridge elements for more realistic looking structure
- Quick means to change plot elements such as line thickness, opacity of substructure, etc.
- Solid earth representation of channel
- Rapid zooming and panning of bridge plots
- Enhanced annotation system
- Integrated Help System

However, compared to the prior versions of *BrEase*, the **C-BrEase** no longer supports the following features:

- Nonbridge Option for cross-sections not located at bridge site
- Clearance Diagram

---

Created with the Standard Edition of HelpNDoc: [Streamline Your Documentation Process with HelpNDoc's Intuitive Interface](#)

---

## Release History

---

### C-BrEase Release History

#### Version 1.0 - Released July 6, 2017

#### Version 1.1.0 - Released September 19, 2017

- Added Option to Name Report Files
- Printing
  - Cleaned up missing legend on charts
  - Removed Status Strip from print
  - Added Paper Size Options
  - Removed bug when printing charts without report
- Editing Annotations on Charts
  - Enabled moving of Bridge Labels
  - Enabled moving of annotations with mouse
  - Enabled changing font size, line size and rock size with mouse
- Fixed Licensing bug which locked out user if wrong password used

#### Version 1.1.1 - Released November 27, 2017

- Added Trace Values of Deck and Soffit on Chart
- Fixed Bug in X-Section Input to prevent hiding of Point Entries upon selecting From Item

#### Version 1.1.2 - February 8, 2018

- Corrected Bug which ignored Vertical Adjustments to X-Sections points on Read-in of \*.cbz file.  
Subsequently, when the file was saved, all Vertical Adjustment Values were being set to False.

#### Version 1.2.0 - July 7, 2018

- Corrected Bug which ignored referencing face of substructure item for station in cross-section calculations
- Added Status Strip help for all fields in form
- Added Hydraulic Module with Rating Curve and Risk Analysis

#### Version 1.2.1 - October 5, 2018

- Added Pier Scour Module based on CSU Pier Scour Equation
- Added Risk Analysis for Pier Scour

#### Version 1.2.2 - February 24, 2019

- Improved validation on Hydraulics module
- Fixed Issue causing the PDF Report to crash
- Fixed Bug with Bridge Labels on Charts
- Reorganized image files in Program directory

#### Version 1.2.3 - March 3, 2019

- Improved Zooming on Charts
- Fixed Bug in Annotations on Charts

- Fixed Bug for Superstructure Length

#### Version 1.2.4 - September 2020

- Improved Chart Labels
- Addition of Markers for Plots
- Rotation of Annotations on Charts
- Bugs fixed for modifying Annotation Table Entries
- Bugs fixed for Saving Chart Images and Printing Charts
- Export for Cross-Sections Added for both Survey Data and General Cross-Sections
- Bug fixes on X-Section Entries
- Bugs fixes for Font Size on Chart Title and Axis Labels

#### Version 1.2.5 - June 2021

- Improved Chart Labels by allowing rotation of text
- Allow for renumbering/renaming of Substructure Item Numbers/Names
- Addition of Import of Cross-Sections from Text File
- Fixed bug in labels using Metric Units

#### Version 1.3.0 - February 2023

- New Annotation Features added including Circle, Rectangle and Free Polygons
- Undo feature added for Annotations

---

Created with the Standard Edition of HelpNDoc: [Keep Your Sensitive PDFs Safe with These Easy Security Measures](#)

---

## Getting Started

---

### Let's Get Started

**C-BrEase** is designed to be an intuitive program which provides the user with a clear and consistent approach to plotting channel cross-sections at bridge openings.

Using As-Built Bridge Plans and field measurements of channel cross-sections, one can develop accurate and professional plots that illuminate channel changes and potential problems at bridge site.

To navigate in **C-BrEase**, one uses User Forms to input data and for commands for generating and modifying plots.

---

Created with the Standard Edition of HelpNDoc: [Maximize Your Documentation Capabilities with HelpNDoc's Project Analyzer](#)

---

## System requirements

### System Requirements

#### Hardware and Software Requirements



The computational and graphical demands for **C-BrEase** are fairly low making the program usable on most PCs and Laptop computers running Microsoft Windows 7 or later.

**C-BrEase** is built on the Microsoft .Net Framework and requires Version 4.5 or later.

---

Created with the Standard Edition of HelpNDoc: [Easily create Web Help sites](#)

---

## Evaluating C-BrEase

### Evaluating C-BrEase

Upon starting C-BrEase for the first time, a 30-day license will be automatically generated. The evaluation license is fully functional, but will place a "Demo Document" watermark on the PDF Report Documents.

After the evaluation period, you will no longer be able to open, modify, save C-BrEase files or in any other way use the C-BrEase program.

To upgrade to a Paid Version of C-BrEase, see the help section on [License Registration](#).

For more information on acquiring a Paid Version of C-BrEase, visit the following [web page](#) or contact [sales@h2floconsulting.com](mailto:sales@h2floconsulting.com) or 916-832-5327.

---


Created with the Standard Edition of HelpNDoc: [Full-featured EBook editor](#)


---

## Getting help

### HELP

#### Help Button

On each user form, a Help Button, , is located at the upper right corner of the form to provide specific guidance for that section of the user form.

After clicking the  button, you can select various items on the form to open the Help file document to the topic which is relevant to the selection.

#### Status Strip

In the lower left corner of the form, instructions are given in the Status Strip for what information or action is required for each field or tool on the form.

To access this information, hover the mouse over the textbox, dropdown box or combo box to see the display in the Status Strip as highlighted in the image below.

**Bridge Substructure Data**

Current Item: 1  
 Name of Substructure Element: ☐ Abutment ☐ Bent ☐ Pier  
 C/L Station (ft): 471+40.50  
 Bridge Skew: 0  
 Apply Variable Structural Depth: Left Side: None, Right Side: None

**Foundation Type**  
 Pile Cap (PC)

**Column Data**  
 Top Width (ft): 1  
 Bottom Width (ft) (if different): 1

**Footing Data**  
 Width (ft): 2.5  
 Thickness (ft): 2.5  
 Bottom Elevation (ft): 240.2

**Pile Data**  
 Pile Width (ft): 1.25  
 Pile Tip Elevation (ft): 211  
 No. of Piles: 1  
 Average C-C Pile Spacing (ft): 1

Buttons: Create New Item, Save Data To List, Delete Item, Duplicate Item, Preview Bridge Item

Item	No.	Station	Bridge Skew	Type	Col. Top Width	Col. Bottom Width	Footing Width	Footing Height	BOF	BOT	Pile Width	PTE	Num Piles	Pile Spacing	Variable Depth Lt. Side	Variable Depth Rt. Side
Abut.	1	471+40.50	0	PC	1	1	2.5	2.5	240.2		1.25	211	1	1	None	None
Pier	2	471+98.50	0	SFS	1	1	5	2	214	211					None	None
Pier	3	472+42.00	0	SFS	1	1	5	2	214	211					None	None
Bent	4	472+85.50	0	PC	1	1	2.5	2.5	241		1.25	211	1	1	None	None

Choose the Type of Foundation for this Substructure Item

To report bugs or if you need additional assistance, please email [support@h2floconsulting.com](mailto:support@h2floconsulting.com)

Created with the Standard Edition of HelpNDoc: [Maximize Your Productivity with HelpNDoc's CHM Help File Creation Features](#)

## Program Organization

## Program Organization

**C-BrEase** uses User Forms to record and display bridge and cross-section data.

The Project Information, Bridge Data and Cross-Section Data is entered and modified through the General Form.

In addition, the General Form is used to Create Charts, Open and Save Files and Print Reports.

Created with the Standard Edition of HelpNDoc: [Easily Add Encryption and Password Protection to Your PDFs](#)


## General Form

## GENERAL FORM

The *General User Form* will automatically be displayed when **C-BrEase** is opened.

## Organization of the General User Form

The **General Form** in **C-BrEase** consists of 6 Tabs (Pages) which show across the User Form as show below.



1. [Project Info](#) - for entering project related information
2. [Vertical Alignment](#) - for specifying the type vertical alignment of the bridge
3. [Cross Slope](#) - for defining the cross-slope and distance to the edge of deck
4. [Superstructure](#) - for defining the structural depth of the bridge
5. [Substructure](#) - for defining the dimensions and elevations of the substructure elements
6. [Cross-Sections](#) - for entering the data about the cross-sections
7. [Hydraulics](#) - for entering hydraulic parameters and executing hydraulic analysis.  
Note: The Tab is only available as an Add-On Extension of **C-BrEase** and will not be visible under the Licensing for the basic program. See [www.h2floconsulting.com](http://www.h2floconsulting.com) for more information about purchasing the Hydraulic Add-On.

One moves between the tabs by clicking on the Tab you want to access.

---

Created with the Standard Edition of HelpNDoc: [Why Microsoft Word Isn't Cut Out for Documentation: The Benefits of a Help Authoring Tool](#)


---

## Chart Form

### CHART FORM

The Chart Form provides a set of tools and commands by which user can easily modify and adjust the Chart generated by **C-BrEase**.

Below are the menu options to control the appearance of the Chart.



1. [File](#) - for managing the project including printing and saving charts
2. [Toggle Cross-Sections](#) - for turning on and off X-sections and modifying the

presentation of the x-section

3. [Layers](#) - for changing the visibility and color of components of the chart
4. [Add](#) - for adding annotation to the chart
5. [Zoom](#) - for focusing on specific parts of the bridge/cross-section

Created with the Standard Edition of HelpNDoc: [Make Documentation a Breeze with HelpNDoc's Clean and Efficient User Interface](#)

## File Organization

### File Organization

There are 4 types of files generated by **C-BrEase**:

1. Project Files for **C-BrEase** are ascii (text) files and may be stored to any location on your hard drive or other storage medium and will have the file extension ".cbz" (i.e., sample.cbz). Information in these files can be viewed using any text editor such as Notepad, Wordpad or Microsoft Word.
2. Image files of the Charts can be saved individually as ".jpg" files.
3. Report files documenting the bridge and cross-section inputs are recorded as PDF files.
4. Hydraulic Risk assessment ascii files used for future scour analysis and recorded as "risk\_estimate.cbz"


Created with the Standard Edition of HelpNDoc: [Free help authoring tool](#)

## General Form


The *General User Form* is comprised of the following 6 Required Tabs and 2 Optional Tabs.


The first 6 Tabs are for the development of the bridge and cross-section plots.

The last 2 Tabs are for the optional license purchase for analyzing hydraulic and scour calculations



In principle, it is best to start with the Project Info Tab, then proceed to completing each subsequent tab moving to the right.

If critical information is missing, you will be alerted by a flashing red dot  when trying to move on prematurely as shown below.



The screenshot shows a dark-themed window titled "Project Information". Inside, there are three input fields: "Bridge Number / ID", "Bridge Name", and "Bridge Location". The "Bridge Number / ID" field has a small red circle with a white exclamation mark next to it, indicating a warning or error. The other two fields are empty.

---


Created with the Standard Edition of HelpNDoc: [Create cross-platform Qt Help files](#)

---


## Menu Items

### General Form Menu System

The Menu system for the General Form consists of the following 3 Items



The Sub Menu Items for the File Menu Item are as follows:



Clicking the AutoSave Menu Item will toggle the program to Save the \*.cbz file every 1 minute.

The Write Report Option will provide the user with a summary PDF report of the data entered for the project, bridge geometry and cross-sections.


The Registration Menu Option provides options to

- View the current registration information,
- Register the program
- Deactivate a License on one computer to move it to another computer




---

The Sub Menu Items for the Chart Menu Item are as follows:




To Plot a Chart of the Data, choose the View Chart Item.

To view a previously saved chart, select the chart of interest (e.g., Chart 1 or Chart 2 in the example above)

---

The Sub Menu Items for the Window Menu Item are shown as below to either Minimize or Maximize the General Form on the Monitor.



---

Created with the Standard Edition of HelpNDoc: [Free Kindle producer](#)


---

## License Registration

### License Registration

**To Register C-BrEase**, select the Register Program Option and form showing the Product ID will appear. Copy the Product ID to the clipboard and mail to [sales@h2floconsulting.com](mailto:sales@h2floconsulting.com). Upon receipt of the Product ID and payment for a license, a Registration Code will be emailed back to you which you can enter in the same form as shown below.

After clicking the Validate Button, you should see a message confirming the validation. To complete the registration, close C-BrEase and restart.





Created with the Standard Edition of HelpNDoc: [Easily create iPhone documentation](#)

## License Deactivation

### License Deactivation

If your license is limited to a specific machine and you want to move the C-BrEase license to another computer, the active license must be deactivated by selecting the menu option below and following the instructions provided on the user form.





Once deactivated, a new license can be acquired from [support@h2floconsulting.com](mailto:support@h2floconsulting.com) following the directions for [License Registration](#).

Created with the Standard Edition of HelpNDoc: [Easily create HTML Help documents](#)

## Project Information

### Project Information

Basic identifying information regarding the project is found on this tab.

The screenshot shows the 'Bridge' application window with the 'Project Info' tab selected. The window has a menu bar with 'File', 'Chart', and 'Window'. The 'Project Info' tab is active, showing four sections: 'Project Information' with text boxes for 'Bridge Number / ID', 'Bridge Name (ft)', and 'Bridge Location'; 'Side of Project' with radio buttons for 'Upstream' (selected) and 'Downstream'; 'Unit System' with radio buttons for 'English' (selected) and 'Metric'; and 'User Info' with text boxes for 'Original User' and 'Current User'.

Specifically, the bridge number or ID, the bridge name and bridge location are recorded on this tab.

In addition, one must select which side of the bridge (upstream or downstream) that will be used for the cross-section location.

The bridge number/ID and side of bridge are used to automatically define the file name for the project (e.g., Bridge 99-0011 with cross-sections on the the upstream side will be named "99-0011 Upstream.cbz").

*Note: If cross-sections will be recorded on both sides of the bridge, then 2 separate **C-BrEase** files will be required. Typically, the only difference between the upstream and downstream bridge data is the direction of the bridge skew and cross-slope information.*

The Unit System (English or Metric) is selected on this tab.

Optionally, the Original User and Current User names can optionally be entered on this page.

Created with the Standard Edition of HelpNDoc: [Produce Kindle eBooks easily](#)

## Vertical Alignment

### Vertical Alignment

Three options are provided to define the vertical alignment of the bridge.

The screenshot shows the 'Vertical Alignment' section with three radio button options: 'Level Grade' (selected), 'Parabolic', and 'Cubic'. Below the 'Level Grade' option, there is a text box and the instruction: 'Use this option for flat bridge decks'.



*Use this option of decks that follow a constant slope*



*Use this option if the highway and bridge are on one or more vertical curves.*


Created with the Standard Edition of HelpNDoc: [Full-featured multi-format Help generator](#)

## Level Grade

### Level Grade

Use this option for flat bridge decks.

All that needs to be entered is the elevation of the layout line for the bridge.



Created with the Standard Edition of HelpNDoc: [Streamline your documentation process with HelpNDoc's WinHelp HLP to CHM conversion feature](#)

## Constant Grade

### Constant Grade

Use this option for bridge decks that follow a constant slope along the full length of the bridge.

To define a constant grade, any point (e.g., beginning of bridge) with a known station, elevation and grade can be used.

#### NOTES

1. The Station information can be entered as a standard number ("110.50" or with the station delineation as "1+10.50"), but will be displayed with the "+" stationing as shown in the diagram below.
2. The slope should be entered as a percentage rather than in decimal form (for a -2.1% slope enter -2.1, NOT -0.021) as shown above.

---

Created with the Standard Edition of HelpNDoc: [Bring your WinHelp HLP help files into the present with HelpNDoc's easy CHM conversion](#)

---

## Vertical Curves

### 1 or More Vertical Curves

Use this option for bridge decks that are on an alignment defined by 1 or more vertical curves.

There is no limit to how many vertical curves can be used with **C-BrEase**.

To define a vertical curve, one must enter the Station, Elevation and Percent Grade at the beginning and end of each vertical curve.

*Like the data for the Constant Grade, the Station data may be entered in either decimal form (123.45) or station notation (1+23.45), but will be displayed in typical station format. The Grade information is entered*

as a percent (e.g, enter 1.25 for 1.25%).

**Vertical Curve Number:** 1

**Define the BVC Data**

Station

Elevation

Percent Grade

**Define the EVC Data**

Station

Elevation

Percent Grade

After entering the BVC and EVC data, click the Save Vertical Curve Data button which will store the data and list it in the drop down box Vertical Curve Number: 1 for later viewing or modification.

To create an additional vertical curve, click the Create New Vertical Curve button.

All of the vertical curve data is displayed in the summary table at the bottom of the form.

Summary of Vertical Curve Values						
No.	BVC Sta.	BVC El.	BVC Grade	EVC Sta.	EVC El.	EVC Grade

Created with the Standard Edition of HelpNDoc: [Simplify Your Help Documentation Process with a Help Authoring Tool](#)

## Cross Slope

### Cross Slope

To adjust the profile grade elevation along the layout line to the elevation at point of the cross-section measurement along the edge of the deck, the cross slope of the bridge deck must be taken into account.

To do this, first enter the

**Distance from Layout Line to Edge of Deck** 11.55

Next, two options are provided to define the cross slope of the bridge deck depending on whether the bridge is located in a super-elevation transition or not.

Select the Type of Cross Slope

☒ Constant Cross

☐ Varying Cross

---


Created with the Standard Edition of HelpNDoc: [What is a Help Authoring tool?](#)

---

### Constant Cross Slope

**Constant Cross Slope** - enter a single value for the cross slope using a negative value when the edge of deck is below the layout line and a positive value if the edge of deck is above the layout line. The value of the cross slope should be entered as a percent (e.g., enter -0.012 if the slope is -1.2%)

Enter the Cross Slope Value




Cross Slope (%)

---

Created with the Standard Edition of HelpNDoc: [Easily create CHM Help documents](#)

---





However, if a bridge has multiple constant structural depths, it is possible to represent this in C-BrEase by creating 2 Varying Structural Depth Templates - each with a constant structural depth for each as shown below.


Distance	Depth
1	2
5	2

Created with the Standard Edition of HelpNDoc: [Effortlessly bring your documentation online with HelpNDoc](#)

## Constant Structural Depth

### Constant Structural Depth

For bridge with a constant depth such as are defined by slabs, box girders and most girders, use the constant structural depth option to define the depth.




Created with the Standard Edition of HelpNDoc: [Effortlessly Convert Your Word Doc to an eBook: A Step-by-Step Guide](#)

## Varying Structural Depth

### Varying Structural Depth

For bridge with a variable structural depth such as arch type bridges, select the check box as below



After checking the box, new input fields will appear for you to define a template for the variable depth. Templates can be defined for either the left or right side of the bridge item, so you will then need to select which side of the substructure item you are creating a



template.

### Variable Structural Depth Data


**Side of Bridge Item**

☒ Left Side
☐ Right Side

After choosing the side of the template, enter points to define the depth of the superstructure as referenced from the centerline of the bridge item.

**Side of Bridge Item**

☒ Left Side
☐ Right Side



CL


Enter Distance and Depth Values  
Defining the Structural Depth

Distance

Depth

Add Variable Depth Pt

After entering the data and clicking the Add Variable Depth Pt button, the data will be recorded the template and displayed in the table the right side of the form and displayed in the preview chart.



You can choose the modify or delete individual data points by right clicking on the value in the table and switch between existing templates by choosing a different template in the drop down box at the top.

### Modifying and Deleting Key Points

To Modify or Delete a Point after it was saved, Right Click on the point your wish to change and select either Edit or Delete from the Context Menu.

Summary of Variable Structural Depth

Distance	Depth
1	7
3	6
7	5
1	4

Context Menu:

- Edit
- Delete

If you choose Edit, then the existing value you selected will be written into the Distance and Depth Boxes where you can change them and resave them by clicking the Modify Variable Depth Button below the values.

## Substructure

### Substructure

#### To Add a New Bridge Item,

Click the **Create New Item** button.

For each bridge item, basic information needs to be entered to describe the type of element, its stationing, the bridge skew of the item and whether a variable superstructure is applied to either side of the bridge item as show below.


Bridge Substructure Data					
Select Item	Name / No.	Name of Substructure Element	C/L Station (ft)	Bridge Skew	Apply Variable Structural Depth
		<input type="radio"/> Abutment <input type="radio"/> Bent <input type="radio"/> Pier			Left Side Right Side
1	1		169+36.05	29	None None

The Name / No. Field is automatically assigned to match the value in the "Select Field" drop down item which would typically be appropriate; however, you may change this value to whatever value or name you wish.


Note: For bridges with As-Built Bridge Labels that are reversed from current naming convention, if you manually replace Name/No value for Item No. 1 with the value of the last Bridge Item No., then you will be asked if you would like to automatically reverse all bridge item names/numbers which can expedite this process if appropriate. This information will be saved in the CBZ file and subsequent Charts will include the bridge labels in reverse order to the bridge stationing.

Bridge Substructure Data	
Select Item	Name / No.
1	1

For bridge skew, enter a positive skew value in degrees if the projected station from the bridge item at edge of deck is farther ahead on station or a negative skew value if it is behind on station as shown below.



Next, the type of substructure of substructure for each bridge item needs to be selected. In **C-BrEase**, there are possible types of substructures available as show below.




Depending on the type of substructure selected, various input textboxes will become visible for you to supply the appropriate geometric information. In all cases the column information is required; however, information regarding piles and tremie seals may or may not be needed depending on the type of foundation.

For the case of pile cap with a tremie seal, all the data fields are required as shown below.

<b>Foundation Type</b> Pile Cap on Seal (PCS)	<b>Footing Data</b> Width: 21 Thickness: 7 Bottom Elevation: 3.9 Tremie Seal Elevation:	<b>Pile Data</b> Pile Width: 1 Pile Tip Elevation: -26.1 No. of Piles: 10 Average C-C Pile Spacing: 2
<b>Column Data</b> Top Width: 13 Bottom Width (if different): 19		

For cases of "Unknown Foundations", only the column information is required. For this case the column will terminate at the ground line in the Chart.

By clicking the **Preview Bridge Item** button, one can preview the individual bridge item.



After entering all of the required information for a particular bridge item, click the **Save Data To List** button to record the data and display it on the table at the bottom of the form.

Note: if a substructure item is inserted with a station between two other substructure stations, the data will be automatically reordered.

### To Modify an Item Numbers Automatically

The Name / No. Field is automatically assigned to match the value in the "Select Field" drop down item when the Substructure item is created.

In some rare cases; however, you may want change this value to a different name or number. For instance, if the naming convention is opposite of the stationing then you may wish to *reverse* the numbering. To reverse the numbering for all items automatically, change the first item number to the last value and you will be asked if you would like C-BrEase to reverse all the values.

For instance, if a bridge has 5 substructure items that you would like to reverse the numbering, then change Item 1 to 5 and agree to have the program change all of the values.

---

Created with the Standard Edition of HelpNDoc: [Make your documentation accessible on any device with HelpNDoc](#)

---

## Cross-Sections

### Cross-Sections

Cross-Section Data consists of the date, measurement offsets, vertical and horizontal measurements and point values and descriptions.


---


Created with the Standard Edition of HelpNDoc: [Easily create iPhone documentation](#)

---

#### Date

#### Cross-Section Date

After clicking the  button, one adds the cross section date by using the calendar.



September, 2016							
Sun	Mon	Tue	Wed	Thu	Fri	Sat	
28	29	30	31	1	2	3	
4	5	6	7	8	9	10	
11	12	13	14	15	16	17	
18	19	20	21	22	23	24	
25	26	27	28	29	30	1	
2	3	4	5	6	7	8	


Today: 9/3/2016

## Type of Cross-Sections

### Type of Cross-Section Data

Three types of data can be used for C-BrEase Cross-Sections:

1. Channel X-Sections - used for cross-sections taken using traditional bridge inspection methods such as a weighted tape or laser.
2. Engineering Plans or Surveys - used when you are entering a horizontal distance and elevation values obtained from traditional survey methods or sonar surveys or from plans such as Foundation Plans and create a list of horizontal distances and elevations.




The screenshot shows a software interface for selecting cross-section data. At the top, there is a label 'Current Cross Section Date' followed by a date input field containing '1/25/1972' and a dropdown arrow. Below this is a section titled 'Type' which contains two radio button options: 'X-Section (Hor + Vert)' and 'Plans / Survey (Hor + El)'. The 'Plans / Survey' option is currently selected.

## Support Data

### Support Data

In the remaining part of the left box,



The screenshot shows a 'Support Data' form with several input fields and checkboxes. The fields are: 'Comments' (a large text area), 'Collected By' (a text field), 'Vert. Dist. from Deck to Measuring Pt. (ft)' (a text field with a subtext '( "+" for Rail and "-" for Soffit )'), 'Vertical Measurement Adjustment (ft)' (a text field with a subtext '(e.g., Tape Leader, Rod Height)'), 'Reference Face of Bridge Item for Horizontal Distances' (a checkbox), and 'Use Constant Elevation for Vertical Reference' (a checkbox). There is also an 'Elevation' label next to a text field.

- Comments can be added such as might relate to the nature, quality or reference of the measurements.
- The name of the inspector can be documented in the "Collected By" field.
- The vertical distance from where the measurement is taken and the edge of the deck can be entered
- A vertical offset such as for a tape leader or rod height can be applied to the collected data
- A checkbox can be selected if the horizontal measurements are referenced to the column face of an element rather than its centerline station.
- If a constant vertical alignment other than the bridge deck is referenced for a cross-section, such as could occur if one were taking depth readings from a boat where the water surface elevation was known, check the box next to "Use Constant Elevation for Vertical Reference", then supply a constant reference elevation for the cross-section points.

Created with the Standard Edition of HelpNDoc: [Produce online help for Qt applications](#)

## Recording Data Points

### Cross-Section Data Points

The actual cross-section points are input in the box at the top.

Pt. No.	From Item	Horizontal Distance	Vertical Distance	Add Vertical Adjustment	Description / Comments (optional)	Next Point
1	1 ▼	-1.08	26.63	<input type="checkbox"/>	▼	

- The point number is automatically generated.
- The "From Item" reflects the bridge item for which the horizontal measurement is based. While commonly this is Item 1 for all points if say all the horizontal readings were taken from the beginning of the bridge, it is possible to reference different items such as when using a laser from below the bridge.
- The Horizontal Distance for the point is commonly positive when all points are taken from a single reference bridge item, but can be entered as negative when the reference item is ahead on station from the measurement point.
- The Vertical Distance as measured.
- The Add Vertical Adjustment adds the vertical offset to the vertical measurement.
- Select from the drop down list or enter your own description of the point as desired.

Click the **Next Point** button to add additional points. This will also record the cross section point and write it onto the summary table as shown below.

**Note:** To modify or delete any particular point, right click on the point of interest and select your desired action.

**If a substructure item is inserted with a station between two other substructure stations, the data will be automatically reordered.**

Pt.	From Item	Horiz. Dist.	Vertical Dist.	Add V Adjust.	Description	Station	Elevation
1	1	-1.08	26.63	False		-9.08	29.89
2	1	1.08	30.7	False		9.08	25.82
3	1	54.56	30.54	False		62.56	25.98
4	1	61.13	35.33	False		69.13	21.19
5	2	-90.65	44.74	False		96.85	11.78
6	2	-40.23	45.92	False	Top Scou...	147.27	10.6
7	2	-33.47	48.55	False		154.03	7.97
8	2	-3.22	54.74	False		184.28	1.78
9	2	3.22	53.54	False		206.72	2.98
10	2	16.08	51.57	False		219.58	4.95
11	2	50.53	47.63	False	Edge of ...	246.03	8.89
12	2	110.24	45.99	False		305.74	10.53
13	3	-37.73	45.66	False	Edge of ...	353.27	10.86
14	3	-9.84	52.55	False		381.16	3.97

Entering Data for Engineering Survey Data or Engineering Plans, the input values will be slightly different.

For Survey data, one enters only the Station and Elevation Value.

For Engineering Plans, one enters the Horizontal Distance and Elevation Value.

Created with the Standard Edition of HelpNDoc: [Effortlessly create a professional-quality documentation website with HelpNDoc](#)

## Exporting Cross-Sections

### Exporting Cross-Sections

Cross-Sections can be exported to a CSV (comma-delimited) format by clicking the **Export XS** button at the bottom of the tab.



Current Cross Section Date

Type

☐ X-Section (Hor + Vert) ☒ Plans / Survey (Hor + El)

Comments

Collected By

Vert. Dist. from Deck to Measuring Pt.(ft)  
( "+" for Rail and "-" for Soffit)

Vertical Measurement Adjustment (ft)  
(e.g., Tape Leader, Rod Height)

Reference Face of Bridge Item  
for Horizontal Distances ☐

Use Constant Elevation  
for Vertical Reference ☐

Clicking the Export XS button will open a new User Form

X-Section Export Options

Choose from the options below to export the current X-Section to a CSV file

Export Type

☒ Bridge X-Section Format

Options

☒ Horizontal Distance from Beginning of Bridge

☒ Vertical Distance from Bridge Deck

☐ Metric

☐ Survey Coordinate Format

On this form, you see two export formats:

#### 1. Bridge X-Section Format

This selection will export each point in the cross-section with horizontal and vertical values.

The user can modify the output if desired in 3 ways:

- i) Use "Horizontal Distance from Beginning of Bridge" to mimick having all horizontal values

starting at the beginning of the bridge.


- ii) Use "Vertical Distance from Bridge Deck" to reference all the vertical measurements to the top of deck at the edge of the bridge.
- ii) Use "Metric" to have both the horizontal and vertical values converted to metric units

## 2. Survey Coordinate Format

This selection is intended to be used if you would like to use the cross-section data in a program requiring Survey Coordinates such as the Surface-Water Modeling System (SMS) by Aquaveo™

Selecting this option will show additional inputs to enter the starting Easting, and Northing values for the cross-section which is not found in **C-BrEase** but will need to be found using another means such as a GPS measurement.

In addition, you will need to enter a bearing line in degrees for the direction of the cross-section using East as 0 degrees and CCW as the direction of the angle.



**Survey Values**

Enter the Coordinate for the 1st Point in the X-Section

Easting (ft)  Northing (ft)

Enter the Bearing Angle  
(Measured CCW w 0 degrees = due East)

Bearing Angle

A circular diagram showing a compass rose with degrees marked at 0, 45, 90, 135, 180, 225, 270, and 315. The North arrow points towards the top.


Clicking the "Export" Button will provide you with an opportunity to name the file and provide a path. By default, the file is named with "BridgeNumber\_xs\_mmddyyyy.csv" and will be stored in the same directory as the cbz file.

## Importing Cross-Sections

### Importing Cross-Sections

Cross-Sections can be imported as text files. This feature was originally intended to be used with the SMS software from Aquaveo when observation lines are drawn along the bathymetry and points are extracted; however, this feature may be useful anytime data exists in a text or spreadsheet file as long as it is saved in the proper file structure and format.

The required format for import is: "Dummy" , "Dummy" , Horz. Distance , Elevation where "Dummy" can be any string or left blank as



To use this feature,

1. Click the **Create New** button under the Cross-Sections Tab and enter the date of the cross-section. A new button will appear at the bottom of the form labeled **Import XS**.

Current Cross Section Date 6/15/2021

Type

☐ X-Section (Hor + Vert) ☒ Plans / Survey (Hor + El)

Comments

Collected By

Vert. Dist. from Deck to Measuring Pt.(ft)  
["+ " for Rail and "- " for Soffit]

Vertical Measurement Adjustment (ft)  
(e.g., Tape Leader, Rod Height)

Reference Face of Bridge Item  
for Horizontal Distances ☐

Use Constant Elevation  
for Vertical Reference ☐ Elevation

Create New Delete Add Points **Import XS**

2. Click the **Import XS** Button and a new user form will appear.

ImportXSection

choose a file

1

Delimiter (default comma) 2

3

4

Import

3. On the user form, you need to

- (1) **Browse** to the file you want to import and select **Open**
  - (2) Enter the type of **delimeter** used in the import file (comma by default)
  - (3) Use the dropdown list to select which **station** at the bridge corresponding to where the imported cross-section is referenced.
  - (4) Enter the **horizontal distance** from the reference station to the first point of the imported cross-section.
- Note: if the first point corresponds to the bridge item station referenced in (3) above, enter 0.*


The cross-section should populate the appropriate fields in the form and let you know the number of points that were imported.

Created with the Standard Edition of HelpNDoc: [Make Documentation a Breeze with HelpNDoc's Clean and Efficient User Interface](#)


## Hydraulics

## Hydraulics

If the Hydraulics and Scour Licensing has been acquired, then two additional Tabs will appear at the Right to access these modules:



The Hydraulics Tab provides 3 tools for the engineer to estimate hydraulic conditions for Cross-Sections in **C-BrEase** as described below. For more information on how to use these tools, click on the corresponding Hyperlinks.



### 1. [Solving with the Basic Normal Depth Hydraulic Calculator.](#)

This tool will estimate either

- the water surface elevation for a known discharge or
- the discharge for a given water surface elevation

The tool is graphical in design and can calculate flows with multiple mannings values, overbanks and for known amounts of backwater.

### 2. [Rating Curve](#)

A Rating Curve can be easily generated for a set of hydraulic parameters providing the flow rate for the range of possible flow levels in the channel

### 3. [Risk Analysis](#)

To help Hydraulic Engineers better understand the possible range of flow conditions and to help define and quantify the uncertainty with Hydraulic parameters, the Risk Estimation Tool provides a power means of running Monte Carlo Simulations for the flow based on the level of uncertainty of the data.

---

Created with the Standard Edition of HelpNDoc: [Easily create HTML Help documents](#)

---

## Normal Depth Calculator

### Normal Depth Calculator

The Hydraulic Calculator is estimates the flow according to a single cross-section via [Mannings Equation](#).

$$Q = AV = \frac{k}{n} AR^{2/3} S^{1/2}$$

where :

**A** is the Flow Area

**V** is the Average Velocity in the Channel

**k** is a conversion coefficient. For English Units  $k = 1.486$  and for Metric Units,  $k = 1.00$

**n** is the Mannings Roughness Coefficient

**R** is the Hydraulic Radius which is equal to the ratio of the Flow Area to Wetted Perimeter of the Channel


**S** is the slope of the channel and equals the hydraulic grade line or energy slope under uniform flow conditions

Inherent in the Mannings Equation is the assumption that flow is "Uniform" or "Normal" meaning that there is no acceleration of the flow. In this condition, the flow upstram and downstream of the cross-section should be identical in depth and velocity. Strictly speaking, for this to be true, there can be no change in

- channel geometry,
- alignment (i.e, no bends),
- roughness, or
- slope.

Other than in laboratory flumes or man-made canals, this will not occur in nature. However, as a rough assumption, Mannings Equation can provide a good estimate of the flow conditions when the above conditions are not severely violated.

The Hydraulic Tab consists of 3 Main Parts shown below:



## 1. Hydraulic Parameter Input

Below are descriptions of the various fields and selection options for the Hydraulic analysis

1.

Case	case3
XS	1/25/1972
Solve	Flow Rate
WSEL 242.05	
Mannings <input checked="" type="radio"/> Single Value <input type="radio"/> Multiple Values 0.0200	
Slope	0.001
Overbanks	Both
Add Left Overbank    Add Right Overbank	
Normalization Angle	0
XS Slices	1

**Case** represents the current simulation parameters. You can create new simulations by choosing "Create New" from the dropdown list.

**XS** allows you to select from any previously saved Channel Cross-Sections to use in the Hydraulic Calculation

**Solve** allows you to choose either to solve for **Water Surface Elevation** from a known Flow Rate or to calculate the **Flow Rate** from a known water surface elevation.

**WSEL** is the user provided Water Surface Elevation used for calculating the Flow Rate or the Calculated Water Surface Elevation when solving for WSEL

#### Mannings Value Options:

You can choose to use a single Manning value for the entire Cross-Section by entering the value in the textbox below  
or choose to use Multiple Mannings Values clicking the radio button then clicking the button below

Mannings	
<input type="radio"/> Single Value	<input checked="" type="radio"/> Multiple Values
Select Mannings on Chart	

and graphically drawing on the Chart the location and values of multiple Mannings Values where the values are shown on the chart and colored by n-values (See chart below)

**Slope** is for entering the channel slope. Use decimal values (e.g., 0.01 for a 1% slope)


**Overbanks** allows you to choose to have a Left and/or Right Overbank defined for the calculations which is essential for obtaining a correct value when floodplains exist. You can add the overbank locations graphically by clicking the appropriate "Add Left Overbank" or "Add Right Overbank" button and graphically

	<p>selecting the station on the chart</p> <p><b>Normalizing Angle</b> is used to correct for Cross-Sections which do not cross perpendicular to the channel. Enter the angle to normalize the flow area.</p> <p><b>XS Slices</b> can be used to dynamically divide the channel into slices (a.k.a., stream tubes) to display graphically on the chart values of velocity, unit flow rate and/or shear stress</p>
--	--

## 2. Graphical Display

Below is an example of an chart of a hydraulic calculation.

Note that the Overbanks are defined, multiple Mannings values are provided and slice information is given.



## 3. Output Table

The results from the Hydraulic Calculation are shown in the Output Table. The values on the Left side represent Channel average values.

On the Right half of the Table the values are separately calculated for each Overbank and the Main Channel.



Output			LOB	Main Ch.	ROB
Total Flow Rate	17881 cfs	Flow Rate	0 cfs	16841 cfs	1040 cfs
WSEL	242.05 ft	Average Velocity	NaN ft/s	14.72 ft/s	6.87 ft/s
Maximum Velocity	22.9 ft/s	Flow Area	0 ft <sup>2</sup>	1245 ft <sup>2</sup>	165 ft <sup>2</sup>
Maximum Flow Depth	22.05 ft	Wetted Perimeter	0 ft	90.1 ft	37.3 ft
Critical Depth	17.56 ft	Composite Manning	0.02	0.02	0.02
Top Width	106 ft	Hydraulic Depth	0 ft	17.96 ft	4.49 ft
Froude Number	0.56	Average Shear Stress	0 lb/ft <sup>2</sup>	0.86 lb/ft <sup>2</sup>	0.28 lb/ft <sup>2</sup>
Hydraulic Radius	11.06 ft				

Created with the Standard Edition of HelpNDoc: [Maximize Your PDF Protection with These Simple Steps](#)


## Rating Curve

### Rating Curve

The Rating Curve shows how the Discharge varies with Depth/Water Surface Elevation. After the Hydraulic Parameters have been entered, then a Rating Curve can be generated by clicking the

Show Rating Chart

button which located to the bottom right of the Chart.



Created with the Standard Edition of HelpNDoc: [Full-featured EPub generator](#)

## Risk Estimate

### Risk Analysis

For each Hydraulic parameter in the Normal Depth Calculation, uncertain may exist regarding the accuracy of the parameter. For instance, through a Hydrologic analysis of a Stream Gage, the a 100-Year Flow Rate (Q100) may be determined; however, there is always a Standard Deviation associated with the value which reflects the level of confidence or uncertainty for the value. The Risk Analysis allows the User to see how

the Uncertainty for Various Parameters may combine to generate a Range of Water Surface Elevations and Velocities by running numerous Monte Carlo simulations.

## Input

To run the analysis for a desired Confidence Value, enter the degree of confidence (1 - 99.9%) in the field as shown below:

<input checked="" type="radio"/> Analyze Distribution of WSEL and Velocities	Confidence Value (%)
--	----------------------


After starting the Risk Analysis, the field for the various parameters will be automatically assigned a Constant Distribution value and filled with the values used in the [Basic Normal Depth Calculator](#). However, the Risk Analysis requires that a least one of the parameters be defined with a "Non-Constant" Probability Distribution Function (PDF) in order to randomly generate different results.

Discharge (cfs)	Constant	2264.91
LOB Mannings Value	Constant	0.111
Main Ch. Mannings Value	Constant	0.111
ROB Mannings Value	Constant	0.111
Slope (ft/ft)	Constant	0.001
Backwater (ft)	Constant	0

To define the Uncertainty for the various Hydraulic Parameters, you can select a PDF type from the drop down list for each item. The options for PDF's are


- A **Constant Value** assumes no uncertainty and the single value shown in the adjacent Text Box will be used for all simulations.
- A **Uniform Distribution** assumes that all values between the minimum and maximum range are equally possible.
- A **Triangular Distribution** assumes that all values will be between the minimum and maximum values, but will be proportionally more likely be randomly selected near the value in the middle Text Box

- A **Normal Distribution** (a.k.a., a Gaussian Distribution) follows a typical Bell shaped curve



By defining the median and standard deviation, the probability of randomly choosing values within

- 1 standard deviation is 68.27%,
  - 2 standard deviations is 95.45%
  - 3 standard deviations is 99.73%
- A **Log-normal Distribution** is a continuous probability distribution of a random variable whose logarithm is normally distributed and will only have positive real values.



## Running a Simulation

After defining the various PDFs for your Hydraulic Inputs, you then choose the level of effort (number of simulations) for the Monte Carlo Simulations

<b>Analysis Effort</b>	<input checked="" type="radio"/> Low <input type="radio"/> Medium
------------------------	---

with Low Effort simulating 5000 cases, Medium Effort simulating 25,000 cases and High Effort Simulating 100,000 cases.

Typically, Low Effort will provide a reasonable estimate for the results.


Click the Analyze Button to start the Simulations

## Output

While the simulation is running, you can see a Histogram for Water Surface Elevation and Main Channel Velocities develop and the corresponding statistical values for each displayed.

At the bottom of the Output, the Confidence Level (default 95%) set in the Input Section will show the value for the Water Surface Elevation and Main Channel Velocity corresponding to the percentage of simulations with values below the required Confidence Level.

In the case below, it was determined that 95% of the simulations had a Water Surface Elevation below 243.13 ft and a Velocity less than 2.46 ft/s.



To Save the Risk Analysis for future use such as for Scour Risk Analysis, Click the



button and the randomly generated parameters and results will be saved in a ascii file called "**risk\_estimate.cbz**".

Created with the Standard Edition of HelpNDoc: [Transform your help documentation into a stunning website](#)

## Scour

## Scour

Project Info	Vertical Alignment	Cross Slope	Superstructure	Substructure	Cross-Sections	Hydraulics	Scour
<div> <div>           Scour Case: <span>Scour1</span> </div> <div>           Hydraulic Case: <span>Case1</span> </div> <div>           X-Section: <span>8/30/2012</span> </div> </div> <div> <b>Scour Analysis Options</b> <div> <input type="checkbox"/> Degradation Analysis           <input type="checkbox"/> Abutment Scour           <input type="checkbox"/> Contraction Scour           <input checked="" type="checkbox"/> Local Pier Scour         </div> <div>Solve</div> </div>							

Selecting the Scour Tab provides access to 4 types of scour analysis as described below; however, in Version 1.2.1 only the Local Pier Scour is currently available.

To use the Scour module, you create a Scour Case which comprises the Hydraulic Case, X-Section and

Scour values. Multiple cases can be saved with variations in any of these parameters.

### [Local Pier Scour](#)

---

Created with the Standard Edition of HelpNDoc: [Easily Add Encryption and Password Protection to Your PDFs](#)

---

## Pier Scour

### Local Pier Scour

The local pier scour computation uses the CSU Pier Scour Equations found in the FHWA HEC-18 Manual, *Evaluating Scour at Bridges, 5th Edition* as shown below in Equation 7.3 of the manual:

$$\frac{y_s}{a} = 2.0 K_1 K_2 K_3 \left( \frac{y_1}{a} \right)^{0.35} Fr_1^{0.43} \quad (7.3)$$

where:

- $y_s$  = Scour depth, ft (m)
- $y_1$  = Flow depth directly upstream of the pier, ft (m)
- $K_1$  = Correction factor for pier nose shape from Figure 7.3 and Table 7.1
- $K_2$  = Correction factor for angle of attack of flow from Table 7.2 or Equation 7.4
- $K_3$  = Correction factor for bed condition from Table 7.3
- $a$  = Pier width, ft (m)
- $L$  = Length of pier, ft (m)
- $Fr_1$  = Froude Number directly upstream of the pier =  $V_1/(gy_1)^{1/2}$
- $V_1$  = Mean velocity of flow directly upstream of the pier, ft/s (m/s)
- $g$  = Acceleration of gravity (32.2 ft/s<sup>2</sup>) (9.81 m/s<sup>2</sup>)

Scour calculations are made 1 pier at a time as selected in the dropdown box. As Input Parameters are entered, intermediate calculations are immediately displayed. After all parameters are entered, the scour elevation is shown at the bottom and displayed graphically. Results can be saved for display on the overall bridge plot shown on the Scour Tab.

Alternatively, input parameters can be estimated using probabilities and the scour determined by [Risk Estimate](#).

Scours

Local Pier Scour

Pier 2

CSU Equation

Input Parameters

Pier Width

1

Pier Type

Multiple Column

Pier Shape, K1

Square Nose, 1.1

Hydraulic Skew (in degree)

5

Number of columns

1

Column Spacing

23

Pier Length

1

K2

1

Bed Forms, K3

Clear-Water Scour, 1.1

Bed Elevation

Local Pier

229.27

Flow Depth

10.73

Velocity

2.07

Wide Pier Reduction, Kw

0

☒ Add Debris

Shape

Triangular

Debris Height

2

Debris Width

34

Effective Pier Width

2.29

Calculations

Scour Depth

3.7

Scour Elevation

225.57

Local Pier

Save Result

Risk Estimate

Created with the Standard Edition of HelpNDoc: [Easily create iPhone documentation](#)

## Risk Analysis for Scour

### Pier Scour Risk Estimate

**ScourRiskEstimate**

Pier No. Pier 2 Bed Elevation 229.27 Confidence Value 95

**Hydraulic Parameters**

☒ User Input ☐ Stored Hydraulic Risk Estimation Browse

Equation Uncertainty Constant 1

Depth Constant 10.73

Velocity Uniform 3 5


Hydraulic Skew Triangular 0 5 15

**Debris Parameters**

Shape Triangular 0.21

Width Constant 34

Height Constant 2




Created with the Standard Edition of HelpNDoc: [Free EBook and documentation generator](#)

## Chart Form

### CHART FORM

The Chart Form provides a visual representation of the bridge and cross-section data. The chart can be modified, saved for future reference and printed for documentation.




Created with the Standard Edition of HelpNDoc: [Bring your WinHelp HLP help files into the present with HelpNDoc's easy CHM conversion](#)

## Creating, Saving and Printing

### CHART FORM - Creating, Saving and Printing

#### Creating a Chart


The Chart Form is created from the General Form using the Chart => View Chart Command from the Menu



#### Saving a Chart as a Image

To Save the Chart as a JPG image for future use, execute the File => **Save Image** Command from the Menu






JPG Images can be imported into documents or further modified using a program like Microsoft Paint.

---


### Saving a Chart for Later Recall

To Save the Chart with User Settings as part of the project file (\*.cbz), execute the File => **Save Chart** Command from the Menu and provide a Name in the textbox adjacent to the Save Chart Command.




### Saving a Chart for Later Recall

To Save the Chart with User Settings as part of the project file (\*.cbz), execute the File => **Save Chart As** Command from the Menu and provide a Name in the textbox adjacent to the Save Chart As Command.




The user's Annotations and Zoom Level will be stored for all Saved Charts and the charts will be recreated when the \*.cbz file is reopened by the User.

After saving the project file, you will be able to reopen the Chart with the Name you identified in the General Form Menu under Chart as




The Chart can be further annotated or modified and resaved using the **Save Chart** command.



## Printing a Chart

To Print a Chart, select the Print Chart Menu Item under File in the Chart Form



This will allow you to select the Printer, then Print Preview the Chart before printing.

Created with the Standard Edition of HelpNDoc: [Effortlessly Edit and Export Markdown Documents](#)

## View Options

### View Options

The Chart in C-BrEase is intended to provide a quick visual display of the historic changes in channel cross sections and the amount of cover or pile embedment remaining the the bridge foundation.

To facilitate this activity, enhanced viewing of the details in the Charts by

- Quick Panning and Zooming
- Comparing Cross-Section Values

## Panning and Zooming

### Panning


To Pan within a Chart, click the Left mouse button and drag the Chart.

---

### Zooming


There are two ways to Zoom into a Chart

1. Move your mouse to the area of interest and rotate the mouse wheel
2. Select the Zoom => Box option from the Menu



and draw a box around the area you wish to Zoom into.


To Zoom back out, the easiest way to to select the Original View Option form the Zoom Menu as below.



## Comparing Values

### Comparing Values of Cross-Section Data

To compare Elevation values of the different cross-sections you can select the TRACE option from the Menu bar or by right clicking on the Chart. Once enabled, you can move your mouse horizontally and see the station at the top of the Chart and the corresponding values of each cross-section as shown below.




Created with the Standard Edition of HelpNDoc: [Full-featured Documentation generator](#)


## Cycling through Cross-Sections

### Cycling Through Cross-Sections

Cycling through the cross-sections allows the user to see the historic sequence for how the channel has changed by having C-BrEase automatically Fade-In and Fade-Out cross-sections chronologically. To activate this command, choose the Cycle X-Section command from the Cross Sections Menu as shown below.



After activating the command, a Toolstripe will appear at the top of the Chart which will allow you to control the cycle program.



Options given are:

1. Push the Pause and Restart button to temporarily stop the program
2. Slide the scroll bar to change the speed of the Fade-In and Fade-Out
3. Select the checkbox to loop the cycle sequence
4. Select the Red Quit but to stop the cycle program

---


Created with the Standard Edition of HelpNDoc: [Create help files for the Qt Help Framework](#)

---

## Modifying the Chart

### Modifying the Chart

To modify the Chart Items, use the Menu at the top of the Chart



From this Menu, you can modify or change the visibility of the bridge and cross-sections or add specific notes or items to customize the presentation of the Chart.

---


Created with the Standard Edition of HelpNDoc: [Experience the Power and Simplicity of HelpNDoc's User Interface](#)

---

## Modifying the Bridge


### Modifying the Bridge

The Chart Menu provides the means to easily customize the bridge.




You can Toggle the Visibility, Color or Material Type of any of the following items

- The Entire Bridge  
*Use this option to make the Superstructure and all of the Substructure Elements the same.*
- The Superstructure  
*Use this option to change only the Superstructure.*
- All Substructure Elements  
*Use this option to change all the Substructure Elements (Columns, Footings, Tremie Seals and Piles).*
- Individual Substructure Elements  
*Use this option to individually change various elements.*



## Changing the Transparency of the Bridge

To make the color of All of the bridge items transparent, select the value of Transparency you desire under the Entire Bridge Menu as shown below.



**Notes:** *Transparency only works when Colors are used for the bridge and will not work for the Materials.*


*The transparency settings will be applied to all bridge superstructure and substructure elements equally.*

Created with the Standard Edition of HelpNDoc: [Easily create Qt Help files](#)

## Toggling the Cross-Sections

### Toggling On and Off the Cross-Sections

You can control which cross-sections are displayed on a Chart through the Cross Sections Menu as shown below.



The cross-sections being currently displayed will have a "check" next to the date.

You can quickly turn all the cross-sections on or off by clicking the "Toggle All" menu Item.

To turn individual cross-sections on or off, click on the specific cross-section of interest.

---

Created with the Standard Edition of HelpNDoc: [Experience the power of a responsive website for your documentation](#)

---

## Customizing the Lines


### Customizing the Cross-Section Lines

You can control the Color, Line Thickness or Line Style from the Menu as shown below.

---

#### Color

The current color is shown in the Menu. If you click the word, "Color" then a color dialog box will open by which you can choose whatever color you would like.




---

#### Line Thickness

The Line Thickness can be adjusted between a value of 1 (thin) to 10 (very thick). The current line thickness is shown with a check mark.



Click on the thickness you would like for the line.



## Line Style

The Line Style can be changed using the Menu.

The choices are Solid, Dashed or Dashed-Dot.




## Markers

The Markers can be customized by size and shape.

### Marker Size

To change the size, select Markers => Size as below



The default setting is Dynamic which will adjust the marker size as you zoom in to maintain a relative constant visual size.


If you want to manually change the size, then you can choose from 1 to 4.

If you do not want to see the Markers, select 0 (OFF)

### Marker Shape

Four marker shapes are available through the menu system as shown below.

Note: The Rectangle shape is the default shape and used for charts without a prior selection by the user.




---

Created with the Standard Edition of HelpNDoc: [Free help authoring environment](#)

---


### **Annotating the Chart**

## **Annotating the Chart**

The add specific, descriptive information on the Chart, use the Annotate Menu Item.

With this Menu Option you have 5 types of information to add to the Chart highlighted in yellow below:

1. [Text](#)
2. [Lines](#)
3. [Rocks](#)
4. [Polygons](#)
5. [Pen](#)




---

Created with the Standard Edition of HelpNDoc: [Make Documentation a Breeze with HelpNDoc's Clean and Efficient User Interface](#)

---


## Text

---

### Adding Text (Comments)

#### To Add Text,

1. Select Text from the Menu.



2. Left click on the location in the Chart to Add the Text
3. Type in the Text
4. To Resize the Font, roll the mouse wheel
5. To complete the Text, left click the chart again.

#### Notes:

1. To Cancel the Text Entry, press the Esc Key prior to the second left click.
2. All alpha numeric character and many symbols are allowed for text.


However, commas are not allowed due to problems created with the file structure.

---


## Modifying Text

#### To Move Text (including bridge item labels)

1. Right click on the chart and choose "Select Annotations Mode" or choose "Select Annotation Mode" from the Menu.




2. Right click and choose the Move Annotations Mode.




3. Move the mouse over the item you want move and it should become italicized.  
Left click on it and drag it to the new location.

### To Rotate Existing Text

1. Right click on the chart and choose "Select Annotations Mode" or choose "Select Annotation Mode" from the Menu.




2. Right click again and choose "Rotate Annotations Mode"



3. Move the mouse over the item you want move and it should become italicized.  
Left click on it and drag to rotate it to a new angle

## To Change Existing Text

1. From the Annotations Menu, choose "Edit Annotations"



- 2, Inside the Annotations Table, you may change the value of the "Attribute" column to the desired text.
3. Click the Save Changes button at the bottom of the Table

---

Created with the Standard Edition of HelpNDoc: [Produce online help for Qt applications](#)


---

## Lines

### Adding Lines

To add lines to the chart, you may select from 3 basic line style types as shown in the Menu:

1. Select from 1 of the 3 line styles from the Lines Menu Item.



2. Move your mouse to the beginning of where you would like to start the line and click to set the anchor point.
3. Move the mouse to where the line should end.
4. Turn the Mouse Wheel to resize the line thickness.  
Note: *To Cancel the Line, press the Esc Key*
5. To end the line, left click at the end of the line.

---

Created with the Standard Edition of HelpNDoc: [Make your documentation accessible on any device with HelpNDoc](#)


---

## Rocks

### Adding a Layer of Rocks

To add rocks to the chart,

1. Select the Rock Option from the Menu.



2. Left click at the beginning of the line of rocks.
3. Move the mouse to where the line should end
4. Rotate the Mouse Wheel to resize the size of the rocks.
- Note: *To Cancel the Rocks, press the Esc Key*
5. To end the rocks, left click at the end point.

---

Created with the Standard Edition of HelpNDoc: [Generate Kindle eBooks with ease](#)


---

## Polygons

### Adding Polygons

Three types of polygons are currently available in **C-BrEase** which are

1. Circle
2. Rectangle
3. Free Polygon




After selecting the type of polygon, you can draw them on the chart.


### Modifying Polygons

To move or resize the polygons (currently this functionality only applies to Circles and Rectangles)


1. Select the Select Annotation Mode from the Menu



- 2A. To MOVE the polygon, left click on the Blue square in the center of the annotation.  
After it changes to Red, you can drag to move the polygon.



- 2B. To CHANGE the SHAPE, left click on the Blue square on the sides of the annotation.  
After it changes to Red, you can drag to re-size the polygon.




---

Created with the Standard Edition of HelpNDoc: [Easy to use tool to create HTML Help files and Help web sites](#)

## Pen

### Using a Pen

If you would like to draw free-hand on the chart, you can use the Pen feature by selecting it on the Menu



Note that the free-hand shapes currently cannot be moved or modified; however, they can be [deleted](#) if needed.

---

Created with the Standard Edition of HelpNDoc: [Effortlessly upgrade your WinHelp HLP help files to CHM with HelpNDoc](#)

---

## Modifying An Annotation

### Modifying An Annotation

---


Created with the Standard Edition of HelpNDoc: [Step-by-Step Guide: How to Turn Your Word Document into an eBook](#)

---

#### Graphically

#### Modifying an Annotation Graphically


To modify an existing annotation using the table, enable this feature from either the Menu or by Right Clicking on the Chart and selecting "Select Annotation Mode" item. After doing so, you will see that it has a check next to the Menu Item as shown below.



Once the Selection Mode is turned on, moving the mouse over a text annotation or bridge label will cause it to change to italic font. Clicking on the word once it is italicized will allow you to move the word or resize it using the mouse wheel.


In Selection Mode, Line and Rock Annotations will display [Blue nodes](#) at the start, end and midpoints.






If you move the mouse over one of the blue nodes, it will change to red and

- if the annotation is a Line, it will become dashed



- if the annotation are Rocks, they will change colors



### Object Modifications Options


1. If you rotate the mouse wheel, the annotation you are on will change size.
2. If you click the beginning or end nodes, you can move the end of the lines.
3. If you click the middle node, you can shift the location of the entire line.
- 4.

### Text Modification Options


If in "Select Annotation Mode", you can modify text by

- Change the size by hovering over the text and rolling the mouse wheel

In addition, by hovering over the text and right clicking you will see the following menu:



- If the Move Annotations Mode is selected as shown above, you can move the text by selecting it with the Left mouse button and dragging
- If you want to Rotate the Text, right click on the text and choose the Rotate Annotations Mode as below.



Once in the Rotation Mode, if you click on the text and drag it, it will pivot as you drag the mouse.

---


Created with the Standard Edition of HelpNDoc: [Elevate Your Documentation Process with HelpNDoc's Advanced Features](#)

---

Tabularly

## Modifying an Annotation Using the Annotation Table

To modify an existing annotation using the table, select the Edit Annotation Item from the Menu



This will display a table of all the annotations on a Chart including the Type, Starting and Ending Coordinates, Size and Attributes as shown below.

AnnotationForm

	No.	Type	Beg. Sta.	Beg. El.	End Sta.	End El.	Size	Attribute
	1	Rock	28439	-9	28493.3	15.23	2	
▶	2	Line	28471.29	-16.11	28493.44	13.61	0	Single Arrow
	3	Comment	28496.14	17.42	28532.73	4.09	19	Rocks
*								

Buttons: Delete Selected Item, Save Changes, Close

To make a change, you can simple type into the cell, the new value (e.g., station, elevation,

size, etc.) and click "Save Changes".

To delete an annotation, select the row by clicking in the left most cell, then click "Delete Selected Item".

---

Created with the Standard Edition of HelpNDoc: [News and information about help authoring tools and software](#)

---


## Removing Annotations

### Removing Annotations

Two commands are available to remove annotations.

#### Undoing the Last Annotation

To remove the Last Annotation, select the "Undo Last Annotation" command from the menu as shown below.



Note: this command can be used successively to remove subsequent annotations; however, once, an annotation is removed, it must be recreated to add it back to the chart.


#### Deleting a Specific Line or Rock Annotations

To remove a specific annotation,

1. Turn on the Select Annotation Mode
2. Hover the mouse over one of the blue nodes
3. Right click and you will see a Delete Annotation Option to remove this annotation or you may click the "Delete" Key on the keyboard.

#### Clearing All Annotations

To remove all annotations from a Chart, simply select the "Clear All Annotations" command as highlighted below.



---


Created with the Standard Edition of HelpNDoc: [Produce Kindle eBooks easily](#)

---

## Writing Reports

# Writing Reports

Documenting your project is easy with C-BrEase.



In the General Form, select the Menu Option under File for Writing a Report

You are then given a choice as to what data you would like to include in the Report.

Check the items as shown below.

**FormReportPickList**

Choose which items you would like to include in the Report

Select All      Select None

☒ Project Information

☒ Vertical Alignment

☒ Cross Slope

☒ Superstructure

☒ Substructure

☒ Cross-Sections

☒ Hydraulics

☒ Scour

Charts

☒ default

☒ akshat

Hydraulic Cases

☒ Case1

☒ case2

Scour Cases

☒ Scour1

Write Report      Cancel

Note: You are able to select any Saved Chart Images to be included in the Report. If no Charts have been "Saved", then you will be given the option to include the Chart showing the full bridge and all cross-sections.

The Hydraulics and Scour check boxes will only be visible if you have the license for these modules.

Finally, you will be prompted to choose a name and location for the file, then a PDF file will be written and displayed on the screen.